How To:

Install MS-995 Carrier Arrows



Prior to installing the arrow on the carrier:

Make sure surface of carrier is clean of dust and dirt. Determine direction the arrow will point when the carrier is installed. Then follow the simple steps below:


Step 1

Noting which direction the arrow will point when the carrier is installed, peel back the edge that will be closest to the factory installed legend about half way.



Step 2

Line up one corner of the arrow sticker with the legend on the carrier making sure that the edge against the legend sticker is parallel to the legend sticker.



Step 3

Once the edge is in the correct position, use your hand to press the arrow sticker onto the carrier while peeling the backing the rest of the way off.



The arrow sticker is properly applied with no bubbles.

